

# Fat Bob Fenders

Our composite fenders are all made at our facility in Upstate New York with all 100% USA made raw materials. Composite glass techniques make our fenders lightweight yet very strong. The top of the rear fenders have been structurally tested to withstand 28,000 PSI, that is stronger than your OEM steel fender. Fenders do not come pre-drilled so you can profile your seat for an exact fit and desired look. We do not guarantee any paint jobs and do not accept fenders back that have holes drilled in them. [See Fender Mounting Tips](#)



## Softail Rear:



### Part # 8725

7 1/8" Softail 1996-2011\*

\$209.00 [Click Here to Order](#)

\*Softail Fender does not fit the Standard, Custom, Fat Boy, or Night Train with 200 rear tire.

## Dyna Rear:



### Part # 8735

8" Dyna 2002-2011\*\*

\$209.00 [Click Here to Order](#)

\*\*Dyna Fender does not fit the Fat Bob with 180 rear tire.

## Sportster Rear:



**Part # 8745**

8" XL 2004+

\$209.00 [Click Here to Order](#)

**Part # 8605XL**

6.75" XL Pre-04

\$209.00 [Click Here to Order](#)

## Universal Rear:



Fatbob w/ built in plate

**Part # 8605**

7.25" Universal

\$209.00 [Click Here to Order](#)

**Part # 8606**

8.25" Universal

\$209.00 [Click Here to Order](#)

**Part # 8606W**

9" Universal

\$209.00 [Click Here to Order](#)

**Part # 8695**

7.25" Universal w/ built in plate

\$219.00 [Click Here to Order](#)

**Part # 8657**

8.25" Universal w/ built in plate

\$219.00 [Click Here to Order](#)

**Part # 8658**

9" Universal w/ built in plate

\$219.00 [Click Here to Order](#)